




GLOWY & ZOEY™ INSTRUCTIONS

WARNING: Children using this product should be kept under close adult supervision at all times. With a curious child, the small snaps and other components could be pulled off creating a choking hazard. LED brightness should be set on the lower settings for children to avoid obscuring vision at night. The LED controller has multiple flashing modes including a strobing effect. This effect should not be used when you or others in the area are sensitive to strobing lights. Do not use if the LED strips have become damaged. Avoid contact with water.


ADDITIONAL INFO: Glowy Zoey LED costumes use LED strips which are made up of sensitive electronic components. Treat them with care as too much bending or pulling can lead to failure. • If any wires become detached from the connectors, controller or LED strips, discontinue use immediately. • Never disconnect connectors by pulling on the wires. • Do not connect the battery box to a charger or an external power source. • Do not immerse in water. The clothing portion can be washed after all electronics are removed. • Controller can be bypassed if it becomes lost or damaged by connecting battery box cable directly to adapter




Remove LED strips, battery box, adapter and controller from the box. Identify the arms, legs, torso and head using the included parts list. Insert 8 AA batteries in battery box and secure with included screw (optional, use if this is for a kids costume).




Locate the pocket on the back of the hoodie. Run the wire from the battery box through the small slit in the bottom left of the pocket. Leave the battery box switch in the off position at this time.




Insert the female end of the controller into a slit at the bottom of the hoodie that is near the back pocket and push it back out to the next slit. Join the controller wire and battery box wire and then push them inside of the hoodie. Flip the hoodie to the front side.




Run the male end of the controller into the next available slit. Place the adapter into the next slit and join to the controller inside the hoodie. **Note:** You can use whatever slits you'd like to run your wiring. You may want to skip some or shift everything over. Do whatever works best for your size suit.




Attach LED leg pairs to the pants using the clear straps. You may want to make adjustments once you have the pants on to allow for bending and movement. Take note of the connectors at the top. You will join these to any 2 of the 3 connectors on the adapter once you have the suit on.




Attach the LED arm pairs to the clear straps. You may want to skip a few straps at first so it's easier to make adjustments once the suit is on.




Attach LED head to hoodie using the clear straps. If you want a rounder shape to the head, use only a few straps at the top. Be sure connector lines up with the very bottom of the head.



Slide the LED torso strip into the clear plastic pieces on the center flap with the 3 connectors side positioned at the top. Connect the connectors to the arms and head. It does not matter which connector you use.



You're almost done! Take a break and have yourself a delicious taco. You deserve it.



Attach the bottom of the torso and the 2 leg connectors to any of the connectors on the adapter. Switch the battery box to the 'on' position and you're good to go! If lights don't turn on, hold down the power button on the controller. You can bypass the controller if it becomes lost or damaged by connecting the battery box directly to adapter.